

Instructions for Use:

Print PDF. Make sure that "Page Scaling" is set to "None". After printing, measure

Squares to ensure they are 1" x 1". Lay paper on area to mount power supply and mark holes. Drill at center of marks with 3/16" drill bit. BE VERY CAREFUL AND DO NOT INSTALL BOLTS MORE THAN 1/8" DEEP INTO POWER SUPPLY AS SHORTING WILL OCCUR!

